


KEEP YOUR SESSION OPEN: LOCK PC WHEN YOU'RE FAR



1





PROXIMITY LOCK RANGE to:
"Out of Range Only (>25 feet)"
Great for small environments where you want to keep your PC unlocked for as long as possible.

2




Set DELAY PROXIMITY LOCK to: **"60 Seconds"**
Set the computer to lock 60 seconds after your token is out of range. This keeps the session unlocked for longer.

3



Set MOTION SENSITIVITY to: **"LOW"**
Delays letting the system know you're leaving and the PC will lock slower.

4



Set SIGNAL QUALITY BIAS level to: **"+10"**
This makes it so that the token seem closer, resulting in a delayed lock.